SMP180 Integrated Digital Receiver

Quick Installation Guide

1. Installation Instruction

1.1 Mounting unit to a 19" rack

When selecting the installation site, try to comply with the following:

- Protective Ground The protective ground lead of the building's electrical installation should comply with national and local requirements.
- Environmental Condition The installation site should be dry, clean, and ventilated. Do not use this equipment where it could be at risk of contact with water.

To avoid electric shock, make sure the rack has been correctly grounded before switching on the device.



PIC-1.1-1 Grounding Jackscrew (must be connected to the rack housing)

To mount the SMP180 unit to a 19"/42U rack, please perform the following steps:

1. Make sure the mounted rack surface is stable and can support the size and weight of this equipment.

2. For single unit mounting, use an "L" shape slide (not included in the package) to support holding the unit if necessary, and fastened with appropriate screws to each side of the chassis' rails.



L-shape slide

3. For group pile up (no space between each unit), the unit should be placed on a flat holding bracket. No more than 5 units for each group, and leave at least one unit space

between each group to ensure good air ventilation.



1.2 Wiring Connection

Before setting up the connection, please turn off the equipment and all other connected external devices. The equipment and all connected external devices are required grounded. Turn on the devices only after the wiring connection is completed. Otherwise the device may be damaged.

Follow the below connection diagram to set up cable connection:





- Set up cable connection for input signal: either the LNB input (area 1), ASI input (area 2) or TS/IP input (area 4)
- Set up cable connection for output signal: either through ASI (area 3) or TS/IP (area 4)
- Set up connection for network management control: shown in area 5.



TIPS In order to ensure a smooth communication between the management PC and the equipment, please separate the connection of management port and TS/IP output port to different switch. The switch with management port connected should be without large data processing.

TIPS The TS/IP port can work for input and output simultaneously. User only needs to connect one RJ45 cable to the TS/IP port of the device.

1.3 <u>Power Connection</u>

Connect this equipment only to the power sources that are identified on the equipment-rating label normally located close to the power inlet connector(s). Always pull on the plug or the connector to disconnect a cable. Never pull on the cable itself.

TIPS To protect your valuable interests and services, equipping a UPS (Uninterrupted Power Supply) and an AVR (Automated Voltage Regulator) to the system is highly recommended.

2. Operation Instructions

2.1 Powering Up & Initializations

REMARKS Before powering-up the device, make sure that all cabling is correctly

connected (refer to chapter 1.2). The device is correctly connected to the power inlet and grounded.

Switch on the equipment through the back power switch, the unit is powered up and start the

initialization.

The LCD screen is lighted up, and display information as following:



PIC-2.1-1

The initialization takes about 30 seconds to complete.



TIPS If the unit fails to initialize and hangs at the "booting" screen, swtiching off the device and then powering up again may help. If the device still fails to initialize,

please contact your service representative for help.



TIPS The input/output indicator LEDs turn red after successful initialization because of signal unlocking. After configuration on the device, corresponding LEDs shall show correct status.

2.2 <u>Network Connection Setup</u>

2.2.1 Navigation Keys Operation Instruction



TIPS Use the 6 navigation keys on front panel: Up / Down / Left / Right / Menu / Ok to

enter the configuration menu.

- Enter "Menu":
 - Press "*MENU*" button to enter main menu.

• Exit Menu/Back to parent Menu

- Upon completion of configuration settings, press "<u>MENU</u>' button until you go back to the Parent Menu.
- You can also go back to Parent Menu directly by pressing "*ESC*" button once.

• Enter Sub-Menu

- Press <u>MENU</u> button to enter main menu.
- Select a sub-menu by pressing arrow <u>UP</u> and arrow <u>DOWN</u> button.
- Press <u>*OK*</u> button on the selected sub-menu.

• To change parameter

- Step 1: Enter main menu by pressing <u>MENU</u> button.
- Step 2: Scroll sub-menu by pressing arrow <u>UP</u> and arrow <u>DOWN</u> button, and press <u>OK</u> button to change the selected sub-menu.
- Step 3: To change parameter settings, press arrow <u>*RIGHT*</u> and arrow <u>*LEFT*</u> button to move the cursor in which change must be made.
- Press arrow <u>UP</u> button and arrow <u>DOWN</u> to input / select an appropriate setting, then press <u>OK</u> button to save.

2.2.2 Check Out and Change the Default IP Address

- Step 1: check out the IP.
- Step 2: change the IP, gateway and subnet mask on the front panel by navigation keys under 'System' sub-menu to make it in the same network section as the management PC. You can also change it in the 'System' tab through Network Management System (as PIC-2.2-1).
- **Step 3:** the equipment will reboot automatically and apply with the new IP address.
- Step 4: ping the new IP on PC to check the connectivity.
- **Step 5:** After IP changes and successful connection setup between the device and management PC, the IP address modification can be done on WEB UI afterwards.

Status Pro	ogram Info Syst	tem 1:CI(HW2) 2:DVB-S	2 3:Empt	y 4:ASI 5:IF	(IO) Licenses	s Upgrade Log
	IP .	Address:	192 . 16	68 . 1 . 242		
	Sub	net Mask:	255 . 255 . 255 . 0			
	Gat	Gateway:		68 . 1 . 1		
	Trap IP Address1: Trap IP Address2:		0.0.0.0 Enable			
	EIT	EITMux:		Disable 🗸 🗸		
	MAC Address:		A0-69-86-00-79-19			
	Mai	MainBoardHardwareVersion:		0		
	MPE	PID:	8189			
	Board Type	Firmware version	Software version			ScanFlash
	MainBoard	V036.0036.20121015		V025.0080.20121	015	
	2xCI New	V201. 2262. 20120918		V142.0050.20120 V151.0156.20120	918	ClearPowerAlarm
	4xDVB-S2_New 4xDVB-S2_New	V143. 1000. 20120925 V143. 1000. 20120925		V101.0035.20120 V101.0035.20120	925 925	Reset
	-					Reboot
						Factory setting
		IP-Set IP-C	Get Ir	nport Expor		

PIC-2.2-1

2.2.3 Configuration through NMS

REMARKS Accessing the equipment through NMS can be very convenient for remote configuration of the equipment. Relative to the front panel settings, NMS operation can provide a more user-friendly man-machine interface, and less limits in space. For quick installation, NMS operation is highly recommended. In this installation guide, operation instruction is based on NMS style. For front panel operation instruction, please refer to product user manual.

- Install the NMS Tool
 - Unpack the accessory CD, and put it on a PC CD/DVD driver;
 - Copy the NMS program on the CD to any folder of the management PC;
 - Use mouse to double click the NMS icon and run the NMS program.



PIC-2.2-2

- First Time Log On
 - For first time log on, User Name and Password are required. Default User Name and Password are "admin".

		×
User:	admin	
Password:	****	
	Remember Me?	
	Login	
	User: Password:	User: admin Password: ***** Remember Me? Login

PIC-2.2-3



TIPS User can change the password after log on the device. Please refer to chapter

2.3.1 of this document for the details.

- Choose "Remember Me" if user wants to directly log on the NMS without inputting the user name and password.
- Select "Login" to log on the device.



TIPS Possible reasons for unsuccessful log on:

- IP address/network mask/gateway doesn't match with the management PC.
- User name/password is wrong.
- The device is connected in the wrong interface.
- Main Interface Introduction

After successful log on, the following screen will display:





The NMS main interface can be divided into four areas according to its functionality.

- (1) **Toolbar:** It includes shortcut to change password and save settings etc.
- (2) Equipment list: If more than one piece of equipment is connected to the NMS, the equipment will be listed in this area by its IP address.
- (3) Parameter setting and configuration area: The parameters of the equipment are shown and configured here by selecting different tabs. This is the main operation area of the NMS. It shares same 6 tabs including 'Status', 'Program Info', 'System', 'License', 'Upgrade' and 'Log'. Specific to each model, the detailed module configuration tab will be different.
- (4) Event information window.

2.3 Quick Configuration on Key Parameters

2.3.1 Change the password

In the 'Toolbar' tab, click 'Password', you can change the password as below:

User:	
Old password:	
New password:	
Retype password:	
	<u></u>



2.3.2 Check 'Status' tab

By selecting this item the NMS displays the current system operation data status of the equipment. User can swtich between tab under the "Status" to check the current working status of the equipment.

NMS Version 1.6.3_20121019_1		
issword AutoLogin Re-Connect Exit Help		
1 A 7 2 0		
5M71800192.168.1.242	SWE100	
	Status (Frages Link) System 1.4.2.002) 2.309-22 (3.2007) 4.821 (5.12.00) Licenses (hyprode, Leg Bandward 1.4.2 (2.00-22 (4.421 (5.12.00))	
	Saven Marco seven Saven Saven Saveno	
	MainDoard TS Bitrate Info	
	Device Name Device Type IV Address Fort Adam Tademation ME1000192 100 1.242 ME100 192 100 1.242 30 device miliant	Alarm Time 2012-10-25 15 25 20

PIC-2.3-2

- 2.3.3 Configure parameters of signal input modules
- Tuner
 - DVB-S/S2 Receiver

Status Program Info System 1:CI (HW2) 2:DVB-S2 3:Empty 4:ASI 5:IP(IO) Licenses Upgrade Log

1	11060.0	27500.000	18V (H) 🗸	Auto 🗸	Single Band 🗸	9750.0	10600.0	Enable 🗸
2	11060.0	27500.000	13V (V) 🗸	Auto 🗸	Single Band 💙	9750.0	10600.0	Disable 🗸
3	11060.0	27500.000	18V (H) 🗸	Auto 🗸	Single Band 💙	9750.0	10600.0	Enable 💙
4	11060.0	27500.000	13V (V) 🗸	Auto 💙	Single Band 💙	9750.0	10600.0	Disable 🗸
4	11060.0	27500.000	13V (V) 🗸	Auto 🗸	Single Band 💙	9750.0	10600.0	Di



In order to receive the input signal successfully, it's important to set the correct parameters in the setting menu.

Key Parameters	Description
Sat Frequency	Input the frequency of transponder which you want to receive
	programs from. The unit is MHz.
Symbol Rate	Input the symbol rate of the transponder. The unit is KS/s.
Polarization	Select the voltage provided to LNB (13V for vertical or 18V for
	Horizontal).
LOLow frequency	The low frequency of LNB. The unit is MHz.

Note: Only LNB 1 & 3 inputs support polarization setting. LNB 2 & 4 can't provide

power (13V or 18V) to the LNB.

After setting all the parameters, you should press 'Set' button to save the settings.

DVB-C Receiver

Port	Frequency(KHz)	Symbol Rate(Ksym/s)	QAM Mode
1	227000	6875	Qam64 🗸
2	243000	6875	Qam64 💙
3	235000	6875	Qam64 💙
4	227000	6875	Qam64 💙

PIC-2.3-4

Parameters	Description
Frequency	Frequency on which the channel is transmitted. The unit is in

	KHz.
Symbol Rate	Symbol rate of the input channel. The unit is in KS/s.
QAM Mode	Select the actual QAM mode of the input channel.

• ASI IN

There are four ASI port in the equipment, the port 1&2 are for input. (The port 3&4 are for

output.)

Status	Program	Info	System	1:CI (HW2)	2:DVB-:	52 3:Empty	4:ASI	5:IP(IO)	Licenses	Upgrade	Log
						Ou	tput				
		Port	Туре	PacketSize	Mode	ConstantRate (Mbit)	MaxRate (Mbit)	e MinRa (Mbit	te)		
		1 [Input 🗸	188 🗸	CBR 🗸	34.037	0.000	0.000			
		2 [Input 🗸	188 🗸	CBR 🗸	34.037	0.000	0.000			
		3 [Outpu 🗸	188 🗸	CBR 🗸	34.037	0.000	0.000			
		4 [Outpu 🗸	188 🗸	CBR 🗸	34.037	0.000	0.000			
				Set	Get	Import	I	Export			

PIC-2.3-5

Key Parameters	Description
Туре	The status of each ASI port is Input or Output. (not editable)
Constant Rate(Mbit)	Set constant bit rate for ASI output.

Note: For the input parameters, it is all automatically obtained by the NMS when connected with the input signal. It is in not editable status.

• TS/IP IN

In the 'Setup' setting menu, user need to set correct parameters for the IP module such as the IP address, subnet Mask, Gateway, etc. so that the module can work normally in the network.

Status Program Info System 1:CIOHW2) 2 Input Output Setup	:DVB-S2 3:Empty 4:ASI 5:IP(IO) Licenses Upgrade Log
	Ethernet:
IP Address:	192 . 168 . 1 . 34
Subnet Mask:	255 . 255 . 255 . 0
Gateway:	192 . 168 . 1 . 1
MAC Address:	A0-69-86-00-79-1A
SpeedMode:	Auto
IGMP Version	IGMF V2
Set	Get Import Export

PIC-2.3-6

The 'Input' setting menu is to set the IP input function for receiving multicast/unicast IP stream.

Status	Program Info Sy	ystem 1:CI(HW2)	2:DVB-S2	3:Empty	4:ASI	5:IP(IO)	Licenses	Upgrade	Log
Input	Output Setup								
	ChannelSelect	Channel1	~		Enab	le	ON	~]
	a)) a c:								
	-Channel Configur	ation:							
		2010			FEC Pa	arameter:—	3		
	EnableChannel	ON	~	BatchSet	ColF	ECSeen	0	×	
	SourceTPAddress	227 . 10 . 20	. 80		PF	PCC	0		
					NOWL	reseen	U	×	1
	SourcePort	1234			FECL		0		
	Protocol	IMP	~				0		1
	C-IR	D: 13			FECD		U		
	Corrortmatching	Disable			Bitrat	o Poromoto			
	RowPortMatching	Disable	~		Diciac	.e iaiamete.			
	IGMPV3SourceAddr	ess 0.0.0	. 0		Bitr	ateMode	VBR	~	
			Set		Get	1			

PIC-6.3-7

Key Parameters	Description			
ChannelSelect	In this 'ChannelSelect', user can select a channel to configure its			
ChannelSelect	parameters.			
	On: enable the IP receiving function.			
Enable	Off: disable the IP receiving function.			
	Note: this parameter setting applies to all channels.			
Channel configuration				

EnableChannel	Enable or disable corresponding input channel		
SourceIDAddress	Set the IP address of the multicast/unicast that are going to		
SourceiPAddress	receive		
SourcePort	Set port of multicast/unicast		
Protocol	Select UDP/RTP for multicast/unicast		
ColPortMatching	If the output IP stream quality looks not as good as the input		
PowPortMotobing	stream, user can select to 'Enable' these two options then to		
RowPonimatching	enable the FEC function.		
	The bigger values it is, the stronger capabilities it has to correct		
FEC Parameter	the data mistakes. But the FECL and FECD should be less than		
	100.		

After setting all the parameters, you should press 'Set' button to save the settings.

2.3.4 Configure parameters of signal output modules

CI •

The CI descrambling module is for descrambling the input scrambled stream via CAM module. The module supports 2 CAMs working simultaneously.

Status Program Info S	ystem 1:CI ORM2) 2:DVB-S2 3	Empty 4:ASI	5:IP(IO) Licenses	Vpgrade Log
CAM	Enable	TSClock	Mode	ConstantRate (Mbit)	
1	Enable 🗸	9MHz 🗸	CBR 🗸	64.000	
2	Enable 🗸	9MHz 🗸	CBR 🗸	64.000	
	_				Reboot
		Set (Get MMI	Power off	Factory setting



In the CI module NMS interface, there are four items for user to select/configure. Only after

the parameters are correctly set can the CI module work normally.

Key Parameters	Description		
----------------	-------------	--	--

	Enableturn on the CI module and enable the input stream			
	to pass through the CI module and get descrambled.			
Enchle/Dischle quitch	DisableDisable any input stream to pass through the CI			
Enable/Disable switch	module and thus the CI module will not be functional.			
	! Please select Disable if no CAM is inserted in the CI			
	module.			
	The TSClock is selected according to the CAM and actual			
	bitrate of input TS.			
	Five options in the TSClock can be selected:			
	9MHzsupport up to 72Mbit input TS.			
	9.5MHzsupport up to 76Mbit input TS.			
	10.5MHz support up to 84Mbit input TS.			
	11.5MHz support up to 92Mbit input TS.			
TSClock	13MHz support up to 104Mbit input TS.			
TSCIUCK	The correct TSClock need to be selected according the			
	inserted CAM processing capability. Usually a standard			
	CAM can support Max. 72Mbit data processing unless it has			
	instruction for higher bitrate support. 9MHz is a default and			
	recommended option for most of the CAMs.			
	! Selecting a wrong TSClock will cause video mosaic			
	issue because the processing data exceeds the CAM			
	Max. data capability.			
	To set a fixed output bitrate for the CI module.			
ConstantRate (Mbit)	! Please set a bigger bitrate value than the input TS rate			
	and reserve a bit buffer.			

• ASI OUT

Please refer to chapter 2.3.3 (ASI IN).

• TS/IP OUT

The "Output" setting menu is to set the IP output function for transmitting multicast/unicast

IP stream.

ChannelSelect	Channel1 🗸 🗸		Enable	ON	-
	Che	nnel Configura	ition:		
EnableChannel	Enable 🗸 🗸	BatchSet	FEC Pa	rameter:	_
SourcePort	10000	Ducciber	EnableFEC	Diasble	-
D (TD) 11			ColFECOnly	Yes	-
DestIrAddress	227 . 10 . 20 . 80		InterleaveMode	Annex_a	~
DestPort	1234		FECL	4	f
Protocol	VDP 🗸		FFCD	5	-
Frank West TCD - slotter			FECD	J	
Encapsumibrackets	r v		Bitrate	Parameter:	- 1
TSPacketSize	188 🗸		Mode	CBR	~
TypeOfService	Normal 🗸		ConstantRate(Mbit)	34. 037	
Time To Live	8		DestMAC	Parameter:	
EnableVLAN	Disable 🗸 🗸		EnableDestMAC	Disable	~
VLAN ID	1		DestMAC	00-00-00-00-00-00	
40.000		Set	Get		

Ρ	IC.	-2.	3	.9
---	-----	-----	---	----

Key Parameters	Description			
ChannelCalent	In this 'ChannelSelect', user can select a channel to			
ChannelSelect	configure its transmitting parameters.			
	On: enable the IP transmission function.			
Enable	Off: disable the IP transmission function.			
	Note: this parameter setting applies to all channels.			
Channel configuration				
EnableChannel	Enable or disable corresponding output channel			
SourcePort	Set port of multicast/unicast			
DestIPAddress	Set IP address of the multicast/unicast.			
Protocol	Select UDP/RTP for multicast/unicast			
Bitrate Parameter				
ConstantRate(Mbit)	Set constant bitrate for output			



2.3.5 Program IN/OUT configuration in 'Program Info' tab



The '**Input Program Configuration**' is on the left side of the '**Program Info**' window. It displays all the modules information and the received input streams. After the parameters of the module are properly configured, select one port which is connected with input stream, and then click the mouse right button and select "Scan TS" menu. All the input stream of that port will be scanned and displayed.







PIC-2.3-12

2.3.6 Check 'Status' again





Turn to '**Status**' tab to check again to make sure the configuration is done. From the mainboard item, user can find the current system operation data status of the equipment. User can swtich between tab under the 'Status' to check the current working status of the sub-module.

• Different colors of histogram indicate different meaning:

Orange: the total input bit rate;

Blue: the effective input bit rate;

Yellow: the total output bit rate;

Green: the effective output bit rate;

Red: alarm indicator, it means the actual output bit rate (it's proportional to the amount of the programs you transfer from input port to output port in '**Program Info**') is more than the output bit rate of some channel you set in sub-module.

Communicate Status indicates the communication status between NMS and the equipment.

Green: the communication is normal. All the parameters in NMS are updated according to the equipment synchronously.

Red: the communication is abnormal. The parameters in NMS may be not updated in time. You need check the network connection and restart the NMS.

After completing the configuration and making sure it's done from checking the status of mainboard and sub-module, user can use device or software which can receive and play ASI or IP stream to test the output stream. For example, if the output stream is IP format, user can send the IP output stream into a PC and test it by VLC software. User should set the IP receiving address in VLC the same as the multicast address of SMP180 IP output, the program content will display if the signal transmission is working.

Note: This Quick Installation Guide only contains tutorials with simple instructions for device installation and configuration. For more information, please refer to the User Manual in the CD packaged with your product.