# UMH160 Integrated Digital Receiver Quick Installation Guide

# **Preface**

# **About This Document**

This document provides introductions and guidelines to users about how to install and operate this equipment quickly.

# Disclaimer

Wellav Technologies Ltd. assumes no responsibility for errors or omissions that may appear in this publication. It reserves the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

# **Intended Readers**

- Technical Service Engineer
- Maintenance Engineer
- Test Engineer
- Sales Engineer

# **Symbols Definition**

For the symbols that might appear in this document, the meanings they represent are as the

following:

Symbol	Meaning
DANGEROUS	There is potential danger. If it cannot be avoided, it will lead to the deaths or serious injury.
WARNING	There is medium or low potential danger. If it cannot be avoided, it will lead to
	medium or mild injury.



# **Revision History**

The revision history lists the modification history. The newest one contains all the

modifications of the past revision.

V1.00: First revision. (Date: March 5<sup>th</sup>, 2012)

# Content

1.	Safe	ty	.5
2.	Che	ck Package and Accessories	.6
3.	Phys	sical specifications	.7
3.	.1	Physical Specifications	.7
3.	.2	Interfaces and data IN/OUT capabilities	.7
4.	Fron	t Panel and Rear Panel	.9
4	.1	Front Panel	.9
4.	.2	Rear Panel	.9
5.	Insta	allation Instruction	10
5.	.1	Mounting unit to a 19" rack	10
5	.2	Wiring Connection	12
5	.3	Power Connection	13
6.	Ope	ration Instructions	14
6	.1	Powering Up & Initializations	14
6	.2	Network Connection Setup	14
	6.2.´	Navigation Keys Operation Instruction	14
	6.2.2	2 Check Out and Change the Default IP Address	15
	6.2.3	3 Configuration through WEB Management	16
6	.3	Quick Configuration on Key Parameters	18
	6.3.1	Check "Status" tab	18
	6.3.2	2 Configure parameters of signal input modules	18
	6.3.3	3 Configure parameters of signal output modules	23
	6.3.4	4 Change the password	28
	6.3.5	5 Check "Status" again	29

## 1. Safety

- To avoid electric shock hazards, do not open the receiver; refer service to qualified personnel only.
- Do not expose the device in the sunlight, and keep it away from the heat source.
- Do not block ventilation holes of the device so that air can circulate freely.
- Switch the device off whenever it remains out of service for an extended period.
- Be sure to turn the device off and disconnect the AC power cord before cleaning the receiver surface.
- The device shall be connected the mains socket outlet with a protective grounded connection
- The appliance coupler used as the disconnect device shall remain readily architecture

# 2. Check Package and Accessories

The Receiver package includes the following accessories:

- UMH160 Base Unit x1
- Power cord x1
- Earth cord x1
- BNC cord x1
- BNC-RCA cord x2
- User manual Disc x1



**REMARKS** Please contact the supplier if it is inconsistent with the actual package.

### V1.1-W

# 3. Physical specifications

# 3.1 **Physical Specifications**

Items	Index
Power	AC 90V-260VAC, 50/60Hz
Power Consumption	Approx 125W
Size	1RU
Dimension	482mm(L) x44mm(W) x 393mm(H)
Net Weight	Approx 3.8Kg
Gross Weight	Approx 5Kg

## 3.2 Interfaces and data IN/OUT capabilities

### **Physical Connector Interfaces**

Inputs	DVB-S/S2 Input
	<ul> <li>Constellation: QPSK, 8PSK</li> </ul>
	<ul> <li>Symbol Rate: 1~45 Mbps</li> </ul>
	<ul> <li>FEC: All rations compliant with standard</li> </ul>
	♦ Signal Level: -65 ~ -25 dBm
	<ul> <li>DVB-T Input(optional)</li> </ul>
	<ul> <li>Contellation: COFDM, 2K &amp; 8K FTT</li> </ul>
	<ul> <li>Symbol Rate: 0.45~7 Mbps (QPSK)</li> </ul>
	Frequency: 174 ~ 230 MHz, 474 ~ 858 MHz
	♦ Signal level: -80 ~ -20 dBm
	<ul> <li>DVB-C Input(optional)</li> </ul>
	<ul> <li>Constellation: QAM ( 16 / 32 / 64 / 128 / 256 )</li> </ul>
	<ul> <li>Symbol Rate: 3 ~ 6.9 Mbps</li> </ul>
	♦ Frequency: 48 ~ 862 MHz
	♦ Signal level: 32 ~ 100 dBuV
	<ul> <li>ISDB-T Input (optional)</li> </ul>
	<ul> <li>Constellation: OFDM (64QAM / 16 QAM / QPSK / DQPSK), 2K, 4K,</li> </ul>
	& 8K FTT
	<ul> <li>Frequency: 470 ~ 806 MHz</li> </ul>
	<ul> <li>Bandwidth: 6 MHz</li> </ul>
	<ul> <li>Input impedance: 75 Ω</li> </ul>
	♦ Input level: -90 ~ -5dBm

Wellav Technologies Ltd.

	DVB-ASI Input
	<ul> <li>Connector: BNC, 75 Ω</li> </ul>
	<ul> <li>Packet Length: 188 &amp; 204 byte packets</li> </ul>
	<ul> <li>TS Max Bit Rate: 72 Mbps</li> </ul>
	<ul> <li>TS/IP Inputs (optional)</li> </ul>
	<ul> <li>Connector: 100/1000Base-T, RJ-45</li> </ul>
	◆ FEC: Pro-MPEG
	<ul> <li>Encapsulation Protocol: UDP &amp; RTP</li> </ul>
	<ul> <li>Broadcasting type: Unicast and Multicast</li> </ul>
Outputs	Video/Audio Outputs
	<ul> <li>2xCVBS outputs (1 BNC, 1 RCA)</li> </ul>
	<ul> <li>1xComponent output (YPbPr)</li> </ul>
	<ul> <li>1xHDMI output (with HDCP, 720p &amp; 1080i)</li> </ul>
	<ul> <li>1xAES/EBU digital audio output</li> </ul>
	<ul> <li>2xHD/SD-SDI outputs (with embedded digital audio)</li> </ul>
	DVB-ASI Outputs
	• Connector: BNC, 75 $\Omega$
	<ul> <li>Packet Length: 188 &amp; 204 byte packets</li> </ul>
	<ul> <li>TS Max Bit Rate: 72 Mbps</li> </ul>
	<ul> <li>TS/IP Outputs (optional)</li> </ul>
	<ul> <li>Connector: 100/1000Base-T, RJ-45</li> </ul>
	♦ FEC: Pro-MPEG
	<ul> <li>Up to 8 streams Multicast or Unicast</li> </ul>
	<ul> <li>Broadcasting type: Unicast and Multicast</li> </ul>
	<ul> <li>Supporting Protocol: DHCP, TCP/IP, ARP, IGMP (V2/V3)</li> </ul>
Analog	• L-AUDIO-R
Analog	<ul> <li>Output Interface: RCA*2, 1 groups of Left/Right Channel audio</li> </ul>
Audio	<ul> <li>Max Output Level: 7 dBu</li> </ul>
Audio	<ul> <li>Output Impedance: 600 ohm</li> </ul>
	• AES/EBU
	<ul> <li>Output Interface: XLR*1</li> </ul>
	<ul> <li>Max Output Level: 2~5V peak to peak</li> </ul>
	<ul> <li>Output Impedance: 110 ohm</li> </ul>
	Management Port
Management	Interface: 100BaseTX,RJ45
	Web-based Management

# 4. Front Panel and Rear Panel

# 4.1 Front Panel



Item No.	Functionality
1	Power status indicator
2	(Signal) Lock status indicator
3	Alarm status indicator
4	LED displaying screen
5	CI SLOTS
6	KEY PADS, including Up/Down/Left/Right arrow keys
7	Menu. To enter the menu and the quit function of the sub menus.
8	ESC. The quit function of the menu.

# 4.2 Rear Panel



Item No.	Functionality
1	TS/IP: TS stream input and output as IP format
2	AES/EBU: Professional digital Audio output with XLR connector.
3	HDMI: Output high quality picture and sound with one cable.
4	Cr/Cb/Y: Component output.
5	VIDEO /AUDIO: Video signal output jack and Left/right audio output jack.
6	ASI IN: BNC connector for TS input.
7	CVBS OUT: Output video with BNC interface.
8	SDI OUT: Output the SDI Video stream.
9	ASI OUT: Output MPEG-2 or Mpeg-4 TS.
10	<b>ETHERNET</b> : The port is used in network remote control.
11	TUNER OUT (LOOP OUT): Use it when connecting to another IRD.
12	TUNER IN: Connect to a RF or IF signal.
13	POWER SUPPLY and POWER SWITCH: 90~250V AC, 50Hz.

**ATTENTION** Inrush Current at initial switch on: 1.55A. Inrush Current after power supply interruption: 2.3A.

# 5. Installation Instruction

# 5.1 Mounting unit to a 19" rack

ATTENTION When selecting the installation site, try to comply with the following:

V1.1-W

- Protective Ground The protective ground lead of the building's electrical installation should comply with national and local requirements.
- Environmental Condition The installation site should be dry, clean, and ventilated. Do not use this equipment where it could be at risk of contact with water.

**WARNING** To avoid electric shock, make sure the rack has been correctly grounded before switching device on the.



PIC-5.1-1 Grounding Jackscrew (must be connected to the rack housing)

To mount the receiver unit to a 19"/42U rack, please perform the following steps:

1. Make sure the mounted rack surface is stable and can support the size and weight of this equipment.

2. For single unit mounting, use an "L" shape slide (not included in the package) to support holding the unit if necessary, and fastened with appropriate screws to each side of the chassis' rails.



L-shape slide

3. For group pile up (no space between each unit), the unit should be placed on a flat holding bracket. No more than 5 units for each group, and leave at least one unit space between each group to ensure good air ventilation. V1.1-W



PIC-5.1-2

### 5.2 Wiring Connection

Before setting up the connection, please turn off the equipment and all other connected external devices. The equipment and all connected external devices are required grounded. Turn on the devices only after the wiring connection is completed. Otherwise, the device may be damaged.

Follow the below connection diagram to set up cable connection:





- Set up cable connection for input signal: either the RF input or ASI input.
- Set up cable connection for output signal: either through ASI or HDMI/ CVBS/SDI.
- Set up connection for network management control.

TIPS In order to ensure a smooth communication between the management PC and

Wellav Technologies Ltd.

the equipment, please separate the connection of management port and TS/IP output port to different switch. The switch with management port connected should be without large data processing.

TIPS The TS/IP port can work for input and output simultaneously. User only needs to connect one RJ45 cable to the TS/IP port of the device.

### 5.3 <u>Power Connection</u>

Connect this equipment only to the power sources that are identified on the equipment-rating label normally located close to the power inlet connector(s). Always pull the plug or the connector to disconnect a cable. Never pull on the cable itself.



TIPS To protect your valuable interests and services, equipping a UPS (Uninterrupted Power Supply) and an AVR (Automated Voltage Regulator) to the system is highly recommended.

### V1.1-W

## 6. Operation Instructions

### 6.1 **Powering Up & Initializations**

REMARKS Before powering-up the device, make sure that all cabling is correctly

connected (refer to chapter PIC-5-2-1). The device is correctly connected to the power inlet and grounded.

Switch on the equipment through the back power switch, the unit is powered up and start the

initialization.

The LCD screen is lighted up, and display information as following:



PIC-6.1-1

The initialization takes about 30 seconds to complete.



TIPS If the unit fails to initialize and hangs at the "booting" stage, swtiching off the device and then powering up again. If the device still fails to initialize, please contact your service representative for help.



TIPS The input/output indicator LEDs turn red after successful initialization because of signal unlocking. After configuration on the device, corresponding LEDs shall show correct statuses.

### 6.2 <u>Network Connection Setup</u>

6.2.1 Navigation Keys Operation Instruction



TIPS Use the 6 navigation keys on front panel: Up / Down / Left / Right / Menu / Ok to

### enter the configuration menu.

- Enter "Menu":
  - Press "*MENU*" button to enter main menu.

### • Exit Menu/Back to parent Menu

- Upon completion of configuration settings, press "<u>MENU</u>" button until you go back to the Parent Menu.
- You can also go back to Parent Menu directly by pressing "*ESC*" button once.

### • Enter Sub-Menu

- Press <u>MENU</u> button to enter main menu.
- Select a sub-menu by pressing <u>UP</u> and <u>DOWN</u> button.
- Press <u>*OK*</u> button on the selected sub-menu.

### • To change parameter

- Step 1: Enter main menu by pressing <u>MENU</u> button.
- Step 2: Scroll sub-menu by pressing <u>UP</u> and <u>DOWN</u> button, and press <u>OK</u> button to change the selected sub-menu.
- Step 3: To change parameter settings, press <u>*RIGHT*</u> and <u>*LEFT*</u> button to move the cursor in which change must be made.
- Press <u>UP</u> button and <u>DOWN</u> to input / select an appropriate setting, then press <u>OK</u> button to save.

### 6.2.2 Check Out and Change the Default IP Address

- Step 1: check out the IP on the LCD screen.
- Step 2: use the button on the front panel to change the IP, gateway and subnet mask. The gateway should be the same as the management PC's. The subnet mask should be the same as the management PC's s. The IP and the server's IP should be in the same section.
- Step 3: reboot the device to take effect.
- Step 4: ping the new IP on PC to check whether the device can connect to the management PC.

### 6.2.3 Configuration through WEB Management

**REMARKS** Accessing the equipment through web can be very convenient for remote configuration of the equipment. Relative to the front panel settings, web operation can provide a more user-friendly man-machine interface, and less limits in space. For quick installation, web operation is highly recommended. In this installation guide, operation instruction is based on web style. For front panel operation instruction, please refer to product user manual.

• Preparation before connection

Open any web browser (e.g. Mozilla, internet explorer, safari etc.), input the equipment's IP address in format: <u>http://xxx.xxx.xxx.xxx</u> (xxx.xxx.xxx refers to IRD's IP address) and press ENTER button to confirm. The browser will attempt to connect to the device. If succeed, a login page will appear (see pic-6-2-1).

- First Time Log On
  - For first time log on, User Name and Password are required. Default User Name and Password are "admin".

→ C ñ 192.168.1.36		☆ <b>전</b> 3 🖲
	User Name	
	Password Clear Submit	

PIC-6.2-1





TIPS User can change the password after log on the device. Please refer to chapter XXXX of this document for the details. (Referring chapter 6.3.4)



TIPS

Possible reasons for unsuccessful log on:

- IP address/ network mask/gateway don't match with the management PC's
- User name/password is wrong.
- The device is connected to the wrong interface.
- Main Interface Introduction

After logging in successfully, it will search the HD IRD which is connected to the server and display it on the left side as below automatically.

					Integrated	Receiver Decoder	
<ul> <li>Status</li> <li>Inputs</li> <li>Receiver</li> </ul>	Lock Status	BER	C/N	Recei	Total TS Rate	Effective TS Rate	
<ul> <li>Outputs</li> <li>Decoder Setup</li> <li>IP</li> </ul>	Doministra Ma	8.010	7.0 00	Outp	uts Status		
<ul> <li>IP Input</li> <li>IP Output</li> </ul>	3905	20	50	3909	3912 Status	0	
<ul> <li>System</li> <li>Local Setup</li> <li>Biss Setting</li> </ul>	CI Status CI Statu FNPTY FINPTY						
Change Password     Factory Setting     Reboot     Upgrade		Refreah					

### PIC-6-2-2

The main interface can be divided into two areas according to its functionality.

1.Menu: It share same 6 tabs including "Status", "Inputs", "Outputs" and "System".

**2.Parameter setting and configuration area:** The parameters of the equipment are shown and configured here by selecting corresponding tabs. This is the main operation area of the WEB management.

## 6.3 **Quick Configuration on Key Parameters**

### 6.3.1 Check "Status" tab

Click the "status" tab on the left area and then the status information will show on the right interface as following, where you can check the main information of the device.

				00.02.02				
			Genera	al Status				
Receiver Lock			Active Alarm			Selected Source		
	Lock		r -	NO		Tunera		
	la hu cun a	DEL CONTRACTO	R	(F 1		ar	Inco	
JERIPER	CON [CEC]	RFLevel (dBm)	Frequency Tune	(MHZ)	Frequency O	fiset [KHz]	FEC	
16-00	52.00	-40	1310.00	5.0	U		Unknown	
	loaurin-t	THE SHALL HERE				and Officer PALIN	ITEO .	
a no	9.10	-76	1209 70	me (mmz)	-200	ancy Unset (KH2)	24	
16-00	3.10	-70	1309.70	eformation	-300		3/4//	
Francing St	ream Rate (MRnc)	17	anenort Stream ID	Original Net	work ID	Stream Date an	f Time	
18.02	ream nate (mpps)	3	anaport offeatimes	2184	INVOINTED	3-Nov-2007 7-22-43		
			TS	etatue				
S rate Mbp	sl		TS effective rate It	Munsi				
18.02			32.87	Hthe Carlor C.				
			Program	Information				
Program Na	me	Program ID	Progra	m Type			CASIFTA	
CCTV-1		301	Digital	television service		1	TA	
			Unit	Identity				
dac Address								
20-12-11-19	-FF-FF							
			Unit V	'ersions				
Software ver	sion	j.	irmware version		Hardwa	re version		
200.0105]20	012-05-25	[:	200.0095]2012-05-24		1			
			CIS	Status				
CI Slot1				CI Slot2				
EMPTY				EMPTY				
			Activo	Alarma				

PIC-6-3-1

### 6.3.2 Configure parameters of signal input modules

Firstly, click the receiver menu to obtain the receiver interface, where you can configure the detailed parameter as follows:

V1.1-W





#### • Tuner IN

If you need to receive the signal from satellite via the device, just connect the satellite signal to the tuner port and operate as follows:

### -Step one:



PIC-6-3-3

Choose the signal as input ,there are three options:ASI, Tuner and IP, here we choose tunel as siganl source. After confirm the signal source, it is able to go for further configuration.

### -Step two:

Configure the dual RF receiver parameters including the Satellite Frequency, Symbol Rate, LNB Frequency, and LNB Voltage (Polarization) with accurate values to ensure a successful receiving. You can get the value for the parameter from the satellite operator

V1.1-W

LNB Frequency:	5150		MHz
Satellite Frequency:	4040		MHz
Symbol Rate:	27500		KBaud
LNB Voltage:	OFF	-	
LNB 22KHz:	OFF	•	
CI MultiDecrypt:	MultiPMT	•	



- **SATELLITE FREQUENCY (MHz):** this is the satellite down conversion frequency, every transponder has one frequency, and this parameter can be obtain from the satellite program provider or at www.lyngsat.com
- SYMBOL RATE (KBaud): every transponder has one symbol rate; this parameter can be obtain from the satellite program provider or at www.lyngsat.com
- LNB LO. Frequency: this is the LNB's local oscillation (LO) frequency, every LNB have one or two oscillation frequencies that can be obtained from the LNB provider, or you can check on the LNB label. The value is between 5000 and 6000..

#### -Step three

By changing the CAM operation, you can determine whether to descramble the program or not.

- **BYPASS:** to transmit the program without any disposal.
- CI SLOT 1 / CI SLOT 2: Common Interface slot. If the program is scrambled, you can appoint the CAM module with CAM Card to scramble it. Under this condition, the program is transmitted in default.
- DELETE: any program you don't want to transmit can be forbidden by selecting this status.

#### -Step four

After that press the "Submit" button to save your settings, and click "Refresh" button to refresh the screen to check if the signal is locked.



#### -Step one

When choosing the ASI signal as input, check the ASI siganl first to ensure a high-quality source, then connect the ASI signal to the ASI interface on rear panel.

#### -Step two

By changing the CAM operation, you can determine whether to descramble the program or not.

- **BYPASS:** to transmit the program without any disposal.
- CI SLOT 1 / CI SLOT 2: Common Interface slot. If the program is scrambled, you can appoint the CAM module with CAM Card to scramble it. Under this condition, the program is transmitted in default.
- DELETE: any program you don't want to transmit can be forbidden by selecting this status.

#### -Step three

Choose the ASI signal as signal source and click "submit" button to confirm. After that click "refresh" button to refrsh the status page to check if the signal is locked.

### • IP IN

### -Step one

When need to choose IP stream as input source, click the sub-menu "IP Input" sub-menu in "IP" menu. Then it can turn to the IP parameter interface.



PIC-6-3-6

#### -Step two

Before the receiving of IP signal, make sure the IP address of the IP board is correctly set. It should be set to be compliant with the signal source.

		Channel configuration					
		EnableChannel:	On	•	•	Γ	Chan Thurse
		Protocol:	UDP		-	L	Step Inree
		MulticastAddress:	227	10	. 20	30	]
		MulticastPort:	1234				
		ColPortMatching:	Enable		-		
		RowPortMatching:	Enable		-		
		IB Board Baramotor					
		MACAddress:	A0-07-EI	D-0F-60	-1E		
	Step two	PAddress:	192	168	.1	.10	
1		SubnetMask:	255	255	255	0	
		Gateway:	192	168	.1	.1	
	ι.						
		FEC Parameter					
		ColFECSeen:	0	,	•		
		RowFECSeen:	0	•	•		
		FECL:	4				
		FECD:	5				



### -Step Three

Then, set the "Enable" item to be "ON" to access the IP channel and set the source IP address, Source Port and Protocol. The Source IP address shall be in the same section with that of signal source, and the Source Port and protocol shall stay same with that of signal source.

### -Step Four

Press "Submit" button to confirm the parameter. And press the "Status" menu in the left area to refresh the receiving information to check if the signal is locked.

### 6.3.3 Configure parameters of signal output modules

### Decoder OUT

The device allows various signal outputs, including HDMI, SDI, CVBS. In this interface, user can view and configure the decoding output program information, including: Video, Audio, and HDMI/SDI.

V1.1-W

Playing Program:	CCTV-1	, <
Video		
Video Standard:	Auto 🗸	-
Screen Mode:	Auto 🗸	-
DVB Subtitle Enable:	Disable 👻	-
DVB Subtitle Language:	None 👻	
EBU Subtitle Enable:	Disable 👻	. 🔪
EBU Subtittle Language:	None 🗸	r Step two
Andia		
Audio lovel:	50	
Audio Neder	Stoves	
Audio Mode:	Stereo +	-
Audio Language:	eng 🔻	
SDI/HDMI:		



### -Step One: choosing programs

• Playing Program:

This interface, all the programs received will be listed in "Source Select" region. By changing the program's operation, you can determine which program to transmit.

Playing Program:	CCTV-1	-		
F	PIC-6-3-9			
REMARKS If the input signal is not locked o	r searched,	the "program"	section sho	ws empty
User cannot do any setup for the moment.				
-Step Two: set program parameter				

### • VIDEO:

Then configure the video parameter such as Video Standard, Aspect ratio Conversion and Output Video resolution as follows:

Video		
Video Standard:	PAL	•
Screen Mode:	Auto	
DVB Subtitle Enable:	Disable	•
DVB Subtitle Language:	None	•
EBU Subtitle Enable:	Disable	Ŧ
EBU Subtittle Language:	None	-



REMARKS The device decoding output is via its CVBS or HDMI output ports. For each

### time only one program can be set to decoding output.

• Audio:

In addition, you can configure the information of Audio such as volume, and audio language,

as following:

	Audio	
Audio Volume(0~49):	þ	
Mixer:	Stereo	
Audio 1 prefered Language:	eng (0x028A)	
Audio 2 prefered Language:	No Audio (0x0000)	



- AUDIO Volume: Set the output audio level from 0 to max. 49.
- AUDIO LANGUAGE: Select different audio language if there are multiple

audio PIDs contained in the signal.

• SDI/HDMI

Here it is able to set the resolution of HDMI or SDI videos.



PIC-6-3-12

### ASI OUT

The ASI interface transmits the received signals out for further process. To guarantee the

Wellav Technologies Ltd.

successful transmission, you should make sure the signal has already been locked.

• IP Out:

When need to choose IP stream as input source, click the sub-menu "IP Input" in "IP" menu.

Then it can turn to the IP parameter interface.



PIC-6-3-13

#### -Step two

Before the setting of IP output channels, you should choose the IP channel that you want to

use. The relative parameter of the channel will appear on the right frame as follow:

Status     Inputs     Decretiver	EnableChannel. UDPSourcePort.	Enable 12345			Program Lis	it No.	Name	Operation
Step Two	IPDestAddress:	227 10 ,20	, 30					<u></u>
• IP Input	Protocol:	UDP						Step Four
Channel1	TimeToLive:	0					L	Steprou
Channel3     Channel4	TSPackets. TypeOfService:	1 Normal	-	_				
Channel5     Channel6	EnableDestMAC:	Disable		$\sim$	、 、			
Channel     Channel8	MACAddress:	00 00 00 00	00 00					
Local Setup     Biss Setting	FEC Parameter				Ste	o Three	2	
Change Password	EnableFEC.	Disable	•					
Factory Setting     Reboot     Upgrade	ColFECOnly: InterleaveMode:	No	-	<b>*</b>				
ob Stanon	Ŀ							
	D:	0						

PIC-6-3-14

### -Step Three

Then, set the "Enable" item to be "ON" to access the IP channel and set IPDestAddress,

Wellav Technologies Ltd.

IPSourcePort and UDPDestProtocol. The IPDestAddress is the address which you want to

send the streams to. (Refer to chapter 6.3.3.3)

Enable the FEC function and set the parameters, if you want this Function.

ColFEConly: No means both Col and Row FEC; Yes means Col FEC only.

#### -Step Four

Here it it able to check the programs that converted in the IP channel.

### 6.3.3.3 Multicast and unicast for IP

multicast application

In multicast application, it is simple to connect the physical equipment, and the following picture shows a typical connection and parameters setting. You just need set the parameters listed in this picture.



#### PIC-6-3-15

The important point is to make sure the multicast address, protocol and port number are the same in both 'IRD\_Sender' and 'IRD\_Receiver'. Regarding how to enter the menu to set these parameters, please refer to the chapter 'front panel/NMS control and operation'.

Note:

V1.1-W

1) The IRD supports IGMP v3, please note the IGMP version that your router supports.

2) The 'Speed Mode' in front panel should be set the same to your switch/router.

3) The quantity of programs transmitted via IP channel depends on the speed mode (10M/100M/1000M) of the switch or router, which connects to the IRD. The total bitrates you want to transmit should less than the most speed which the switch or router takes, otherwise, the quality of programs will decrease, even the programs cannot be transmitted through switch or router.

unicast application

The unicast involves two local area networks connecting each other via Internet. Compare with multicast, the connection and parameter setting of unicast are a little complicated. The following picture shows a typical connection and parameter setting for unicast application. You need set the parameters listed in this picture.





### 6.3.4 Change the password

Choose "User management" menu and you will get the operation interface. Select the username and input the old password correctly, then you are able to change the password. After inputting the new password, please click submit button to enforce the configuration.

	Integrated Receiver Decoder
User: Old Password: New Password: Confirm Password:	
Sub	mit

PIC-6-3-17

## 6.3.5 Check "Status" again

Turn to status page to check if the configuration has come into effect.

					Integrated	Receiver Decoder			
<ul> <li>Status</li> <li>Inputs</li> </ul>	Lock Status	BER	C/N	Recei	iver Status	Effective TS Rate			
<ul> <li>Receiver</li> <li>Outputs</li> </ul>	TunerLock	8.0*10-7	7.0 dB	-75.0 dBm	38.014217 Mbps	35.000198 Mbps			
<ul> <li>Decoder Setup</li> </ul>				Outp	uts Status				
v IP	Program No.	PMT PID		Video PID	Audio1 PID	Audio2 PID			
IP Input     IR Output	3905	26	0	3909	3912	0			
<ul> <li>System</li> </ul>		CI Status							
<ul> <li>Local Setup</li> </ul>	CI Slot1	CI Sidt CI Sidt							
<ul> <li>Biss Setting</li> </ul>	EMPTY	EMPTY EMPTY							
Change Password     Factory Setting     Reboot     Upgrade		Refresh							

### PIC-6-3-18

This is the brief introduce of quick installation, if need more detail or complete information for the device please refer to the user manual.