



969 Horsham Road, Horsham, PA 19044 USA  
Tel: 215-675-2053 Fax: 215-675-7543  
www.tonercable.com info@tonercable.com

## **SANYO** DP19648-RM *Rackmount LCD HDTV*

Thank you for purchasing this rack mount HDTV from Toner Cable Equipment, Inc. This TV is easily mounted in any standard 19" relay rack or cabinet with the enclosed rack mount bracket.

### **MOUNTING INSTRUCTIONS**

1. Unpack the rack mount bracket as well as the Sanyo DP19648 TV.
2. Find the four (4) mounting screws included with the TV.
3. Loosely install these in the corresponding mounting holes on the back of the TV. Leave about 3/16" of the screw protruding from the TV back.
4. Using eight (8) standard rack mount screws, mount the rack mount panel in the rack in its desired location.
5. Secure the screws tightly.
6. The four (4) corresponding mounting holes in the mounting bracket are "keyhole" design. This allows you to install the TV from the front of the rack.
7. From the front of the rack, using the four (4) mounting screws previously installed in Step 3, carefully line up the screws with the keyholes in the mounting bracket. Push the TV towards the mounting bracket making about ¼ inch engaging the screw heads in the slotted part of the keyhole. **Make sure the TV is secure before letting go!**
8. From the back of the rack, tighten the four (4) mounting screws. Be careful not to over tighten the mounting screws.
9. It is normal for the top of the TV to tilt forward. This is due to the design of the TV.
10. Cables can be connected to the various connectors through the access cutout on the right side of the mounting bracket.
11. Use care when installing in light duty racks that the rack does not tip forward when the TV is mounted.



CAUTION

**DO NOT TRANSPORT A HEADEND RACK WITH THE TV MOUNTED, DAMAGE TO THE TV WILL OCCUR. REMOVE THE TV FROM THE MOUNTING BRACKET BEFORE MOVING OR TRANSPORTING THE HEADEND RACK.**